

# Parts display



Step 3 Handrail screws **E** M6X30 6PCS  
 Step 4 Tray screws **C** M6X20 4PCS  
 Step 5 Connect the back frame and tray **A** M8X45 3PCS  
 Step 6 Install the headrest **D** M6X40 2PCS

# Installation Steps



1. Insert wheel X5 into the chair leg



2. Gas bar insert foot



3. Install the handrail with screws (**E**)



4. Install the tray with screws (**C**)



5. Use screws (**A**) to connect the backrest and tray (**gasket required**)



6. Install the headrest with screws (**D**)



7. Install the silver cover



8. Align the holes on the chassis and insert the gas rod



9. Installation Complete